CONTENTS

INTRODUCTION 1	INSTALLATION 3
STANDALONE MODE 5	CONTROLLER MODE 12
WIEGAND READER MODE 14	ADVANCED APPLICATION 15

INTRODUCTION

The device is a single door multifunction standalone access controller or a Wiegand reader with 125KHz RFID card/fob and keypad functionality. The operation is very user-friendly, and low-power circuit makes it long service life.

The device supports 1,000 users (988 common users + 2 panic users + 10 visitor users), all user data can be transferred from one to another (except fingerprint users). It supports multi access modes in card access, PIN access, fingerprint access, card + PIN access, or multi cards access. It supports many kinds of alarms, including tamper alarm, enrollment, interlock, Wiegand input & output interface...etc.

Three Versions Optional:
The device with Bluetooth function is optional
The device with big user capacity is optional
The device with WiFi function is optional

Features

- Capacitive fingerprint sensor, Touch key
- Metal case, anti-vandal
- Waterproof, conforms to IP66
- One relay, 1,000 users (988 common + 2 panic + 10 visitor)
- 125KHz EM card, optional
- EM card, EM+ Mifare cards optional
- EM card: Wiegand 26~44 bits input & output
  Mifare card: Wiegand 26~44bits, 58bits, 58bits input & output
- Can be used as Wiegand reader with LED & buzzer output
- Tamper alarm output
- Tri-color LED status display
- Integrated alarm & buzzer output
- Pulse mode, Toggle mode
- User data can be transferred (except fingerprint users)
- 2 devices can be interlocked for 2 doors
- Built-in light dependent resistor (LDR) for anti tamper
- Backlit keypad, can set automatic OFF after 20 seconds

Specifications

User Capacity	**1000**
Common User	988 / 100 Fingerprint + 888 Card/PIN Users)
Panic User	2
Visitor User	10
Operating Voltage	**12~18V DC**
Working Current Idle Current	<150mA >50mA
Proximity Card Reader Radio Technology Read Range	**EM / EM + Mifare** 125KHz / 125KHz + 13.56MHz 2~6 cm
PIN Length	**4~6 digits**
Wiring Connections	**Relay Output, Exit Button, Alarm, Door Contact, Wiegand Input, Wiegand Output**
Relay Adjustable Relay Output Time Lock Output Load	**One (NO, NC, Common)** 0~99 Seconds (5 seconds default) 2 Amp Maximum
Wiegand Interface PIN Output	**EM card: Wiegand 26~44 bits input & output** **Mifare card: Wiegand 26~44bits 58bits, 58bits input & output.** (Factory default: Wiegand 26bits for EM card, Wiegand 34bits for Mifare card) **Wiegand 4 bits / 8 bits / 26 bits Virtual Number** (Factory default 4 bits)
Environment Operating Temperature Operating Humidity	**Meets IP66** -30℃ ~ 60℃ (-22℉ ~ 140℉) 0%RH~98%RH
Physical Colour Dimensions Unit Weight Shipping Weight	**Zinc Alloy (A/B) A/B/S(C)** Silver & Black (A/B) Black(C) L148 x W43.5 x D22 (mm) – A/C L165 x W44 x D22 (mm) – B 330g – A 419g – B 195g – C 405g – A 500g – B 280g – C

Carton Inventory



INSTALLATION

- Remove the back cover from the unit
- Drill 2 holes(A,C) on the wall for the screws and one hole for the cable
- Knock the supplied rubber bungs to the screw holes(A,C)
- Fix the back cover firmly on the wall with 4 flat head screws
- Thread the cable through the cable hole(B)
- Attach the unit to the back cover



Wiring

Wire Color	Function	Notes
Basic Standalone Wiring		
Red	DC+	12~18V DC Power Input
Black	GND	Negative Pole of DC Power Input
Blue	Relay NO	Normally Open Relay Output (install diode provided)
Purple	Relay Common	Common Connection for Relay Output
Orange	Relay NC	Normally Closed Relay Output (install diode provided)
Yellow	OPEN	Request to Exit(REX) Input
Pass Through Wiegand Reader or Controller		
Green	Data 0	Wiegand Output (Pass-through) Data 0
White	Data 1	Wiegand Output (Pass-through) Data 1
Advanced Input and Output Features		
Gray	Alarm Output	Negative contact for Alarm
Brown	Contact Input	Door/Gate Contact Input (Normally Closed)

Sound and Light Indication

Operation Status	LED	Buzzer
Stand by	Red light bright	--
Enter into programming mode	Red light stroke	One beep
Exit from programming mode	Green light bright	One beep
Operation error	Red light stroke	Three beeps
Exit from the Programming mode	Red light bright	One beep
Open lock	Green light bright	One beep
Alarm	Red light Stroke quickly	Beeps

Basic Configure

Enter and Exit Program Mode

Programming Step	Keystroke Combination
Enter Program Mode	*** (Master Code) #** (Factory default is 123456)
Exit Program Mode	*

Set Master Code

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Update Master Code	**0 (New Master Code) # (Repeat New Master Code) #** (Master code is any 6 digits)
3. Exit Program Mode	*

Set the Working Mode

Notes: The device has 3 working modes: Standalone Mode, Controller Mode, Wiegand Reader Mode, choose the mode you use. (Factory default is Standalone Mode / Controller Mode)

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Standalone/Controller Mode **OR** 2. Wiegand Reader Mode	**7 # (Factory default)** **7 1 #**
3. Exit	*

STANDALONE MODE

The device can work as Standalone Access Control for single door. (Factory default mode) — 7 1 #

Connection Diagram

Common Power Supply

Attention:
Install a 1N4004 or equivalent diode is needed when use a common power supply, or the keypad might be damaged. (1N4004 is included in the packing)

Access Control Power Supply



Programming

Programming will be very depending on access configuration. Follow the instructions according to your access configuration.

Notes:
> **User ID number**: Assign a user ID to the access fingerprint/ card/ PIN in order to track it.

The Common User ID:
- Fingerprint/ card User ID: 0 ~ 98
- PIN/ Card user ID: 100 ~ 987
- Master Fingerprint User ID: 99
- Panic User ID: 988~989
- Visitor User ID: 990~999

IMPORTANT: User IDs do not have to be proceeded with any leading zeros. Recording of User ID is critical. Modifications to the user require the User ID be available.

> **Proximity Card:**
Proximity Card: EM card/ EM+ Mifare cards

> **PIN:** Can be any 4~6 digits except 8888 which is reserved.

Add Common Users
(Fingerprint user ID: 0 ~ 98, PIN/ Card user ID: 100 ~ 987; PIN length: 4~6 digits except 8888)

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
Add Fingerprint User	
2. Using Auto ID (Allows the device to assign Fingerprint to next available User ID number)	**1 (Fingerprint) (Repeat Fingerprint again)** Fingerprints can be added continuously.
OR 2. Select Specified ID (Allows Master to define a specific User ID to associate the fingerprint to)	**1 (User ID) # (Fingerprint) (Repeat Fingerprint) (Repeat Fingerprint again)** Fingerprints can be added continuously.
3. Exit	*

Add Card User

2. Using Auto ID (Allows the device to assign Card to next available User ID number)	**1 (Read Card) (Input 8/10/17 Digits Card Number) #** The cards can be added continuously.
OR 2. Select Specific ID (Allows Master to define a specific User ID to associate the card to)	**1 (User ID) # (Read Card) (Input 8/10/17 Digits Card Number) #**
OR 3. Add Card Block Enrollment (Allows Master to add up to 988 cards to the Reader in a single step) Takes 2 minutes to program.	**1 (User ID) # (Card Quantity) # (The First Card 8/10/17Digits Number #)** Cards' number must be consecutive. Card quantity = number of cards to be enrolled.

Add PIN User

2. Using Auto ID (Allows the device to assign PIN to next available User ID number)	**1 (PIN) #** The PINs can be added continuously.
OR 2. Select Specific ID (Allows Master to define a specific User ID to associate the PIN to)	**1 (User ID) # (PIN) #**
3. Exit	*

Tips for PIN Security (Only valid for 6 digits PIN):

For higher security we allow you to hide your correct PIN with other numbers in front and/or behind it.
Your real PIN: 123434
You could use "**1**123434" or "123434**1**"
(* can be any numbers from 0~9)

Add Master Fingerprint (By Specified ID: 99)

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
1. Add Master Fingerprint	**1 (99) # (Fingerprint) (Repeat Fingerprint) (Repeat Fingerprint again)** Fingerprints can be added continuously.
3. Exit	*

Add Panic Users (Valid for Card/ PIN Users)
(User ID number is 988, 989; PIN length: 4~6 digits except 8888)

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Add Card **OR** 2. Add PIN	**1 (User ID) # (Read Card / Input 8/10/17Digits Card Number) #** **1 (User ID) # (PIN) #**
3. Exit	*

Add Visitor Users (Valid for Card/ PIN Users)
(User ID number is 990~999; PIN length: 4~6 digits except 8888)
There are 10 groups Visitor PIN/card available, the users can be specified up to 10 times of usage, after a certain number of times, i.e. 5 times, the PIN/card become invalid automatically.

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Add Card **OR** 2. Add PIN	**1 (User ID) # (0~9) # (Read Card) / (Input 8/10/17 Digits Card Number) #** **1 (User ID) # (0~9) # (PIN) #** (0~9 means times of usage, 0=10 times)
3. Exit	*

Change PIN Users(PIN length: 4~6 digits except 8888)
(Notice: WiFi versions don't support change PIN)

Programming Step	Keystroke Combination
Note: Below is done outside programming mode, users can undertake this themselves	
Change PIN	*** (User ID) # (Old PIN) # (New PIN) # (Repeat New PIN) #**
Change PIN of Card + PIN access mode (There will auto allocate PIN (8888) to cards when adding)	*** (Read Card) (Old PIN) # (New PIN) # (Repeat New PIN) #**

Delete Users

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Delete User- By Fingerprint/ Card/ PIN **OR** 2. Delete User - By ID number **OR** 2. Delete User - by Card number **OR** 2. Delete ALL Users	**2 (Input Fingerprint)/ (Read Card)/ (Input PIN) #** The users can be deleted continuously. **2 (User ID) #** **2 (Input 8/10/17 Digits Card Number) #** **2 (Master Code) #**
3. Exit	*

Set Relay Configuration
The relay configuration sets the behaviour of the output relay on activation.

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Pulse Mode **OR** 2. Toggle Mode	**3 (1~99) #** (factory default) The relay time is 1-99 seconds. (Default is 5 seconds) **3 0 #** Sets the relay to ON/OFF Toggle mode
3. Exit	*

Set Access Mode
For Multi user access mode, the interval time of reading can not exceed 5 seconds, or else, the device will exit to standby automatically.

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Fingerprint Access **OR** 2. Card Access **OR** 2. PIN Access **OR** 2. Card + PIN Access	**4 0 #** **4 1 #** **4 2 #** **4 3 #** (WiFi versions don't support this function)

Simplified Instruction

Function Description	Operation
Enter the Programming Mode	*** + Master Code + #** then you can do the programming (123456 is the factory default master code)
Change the Master Code	**0 (New Code) # + Repeat the New Code #** (code: 6 digits)
Add Card User	**1 + Read Card + #** (can add cards continuously)
Add Fingerprint User	1+Fingerprint+ Repeat Fingerprint+ Repeat Fingerprint Again #
Add PIN User	**1 + PIN + #** (The PIN is any 4~6 digits except 8888 which is reserved.)
Delete User	**2-Fingerprint- #** **2-Read Card- #** **2-PIN- #**
Exit from the Programming Mode	*
How to release the door	
Fingerprint User	Input Fingerprint
Card User	Read Card
PIN User	Input PIN #

2. Multi User Access **OR** 2. Fingerprint or Card or PIN Access	**4 3 (2~9) #** (Only after 2~9 valid users, the door is opening) **4 4 #** (factory default)
3. Exit	*

Set Strike-out Alarm
The strike-out alarm will engage after 10 failed entry attempts (Factory is OFF). It can be set to deny access for 10 minutes after engaging or disengage only after entering a valid Fingerprint/ card/ PIN or Master code/ fingerprint/ card.

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Strike-Out OFF **OR** 2. Strike-Out ON **OR** 2. Strike-Out ON (Alarm) **Set Alarm Time**	**6 0 #** (factory default) **6 1 #** Access will be denied for 10 minutes (Exit button is **still** workable) **6 2 #** **5 (0 ~ 3) #** (factory default is 1 minute) Enter Master Code # or Master Fingerprint/ Card or valid user fingerprint/ card/ PIN to silence
3. Exit	*

Set Door Open Detection

Door Open Too Long (DOTL) Detection
When use with an optional magnetic contact or built-in magnetic contact of the lock, if the door is opened normally, but not closed after 1 minute, the inside buzzer and external alarm (if there is) will beep to remind the close door. The beep can be stopped by closing the door, master users or valid users, or else, it will continue to beep the same time with the alarm time set.

Door Forced Open Detection
When use with an optional magnetic contact or built-in magnetic contact of the lock, if the door is opened by force, the inside buzzer and external alarm (if there is) will both operate, they can be stopped by master users or valid users, or else, it will continue to sound the same time with the alarm time set.

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Disable Door Open Detection Enable Sound **OR** 2. Enable Door Open Detection **Set Alarm Time**	**6 0 #** (factory default) **7 1 #** (factory default) **6 4 #** **5 (0 ~ 3) #** (factory default is 1 minute)
3. Exit	*

The function of **Set Alarm Time** also apply for anti-tamper alarm

Set Audible and Visual Response

Programming Step	Keystroke Combination
1. Enter Program Mode	*** (Master Code) #**
2. Disable Sound Enable Sound	**7 0 #** **7 1 #** (factory default)
3. LED Always OFF LED Always ON **OR** 3. Keypad Backlit Always OFF Keypad Backlit Always ON **OR** 3. Keypad Backlit Automatic OFF	**7 2 #** **7 3 #** (factory default) **7 4 #** **7 5 #** **7 6 #** (factory default) Automatic OFF after 20 seconds, it will go ON by pressing any key (this key isn't taken into consideration)
3. Exit	*

Master Fingerprint/ Card Usage

Using Master Fingerprint/ Card to add and delete users	
Add Fingerprint/ Card/ PIN Users	1. Input (**Master Fingerprint / Card**) 2. Input (**Fingerprint three times**) **(Card once)** Repeat step 2 for additional users 3. Input (**Master Fingerprint / Card**) again
Delete Fingerprint/ Card/ PIN Users	1. Input (**Master Fingerprint/ Card**) **Twice within 5s** 2. Input (**Fingerprint**) or (**Card**) or (**Key**) Repeat step 2 for additional users 3. Input (**Master Fingerprint/ Card**) again

Users Operation & Reset to Factory Default

> **Open the door**: Read valid user fingerprint or user card or input valid user PIN.

> **Remove Alarm:** Enter Master Code # or Master Fingerprint/ Card or valid user fingerprint/ card/ PIN.

> **To reset to factory default & Add Master Card**: Power off, press the Exit Button, hold it and power on, there will be two beeps, then release the exit button, the LED light turns into yellow, then read any 125KHz EM card/ 13.56MHz Mifare card, the LED will turn into red, means reset to factory default successfully. Off the card reading, it is the Master Card.

Remarks:
① If no Master Card added, must press the Exit Button for at least 5 seconds before release (this will make the previous registered Master Card invalid)
② Reset to factory default, the user's information is still retained.

CONTROLLER MODE

The device can work as Controller, connected with the external Wiegand reader. (Factory default mode) — 7 7 #

Connection Diagram

Power Supply
Door Contact
Exit Button
Alarm
Lock
NC
COM
NO
DC+
GND
OPEN
Alarm
Door Contact
Exit Button
Lock Power Supply
Power Supply
Wiegand Reader
Wiegand Output
Power Supply
Power Supply
Wiegand Reader
Wiegand Output
Power Supply
Power Supply
Wiegand Reader
Wiegand Output