

Bluetooth remote control manual

Before adding Bluetooth remote control requires binding administrator fingerprint.

1. Long press the setting key for 5 seconds to enter the setting menu, verify the administrator's fingerprint, and single-press the setting key to the "Add Bluetooth remote control" display prompt: **Waiting RC**



2. Press and hold the Bluetooth remote control for 4 seconds. When the indicator light changes from red to colored light, release and wait for the connect



3. Unlock way
Single press the bluetooth remote to unlock

4. 8 pcs Bluetooth remote control can be add

5. Delete the Bluetooth remote control

- 1) Clear ALL Bluetooth remote controls

Enter the setting menu, single-click the setting key to "Empty Bluetooth remote control", verify the administrator's fingerprint to clear

- 2) Empty a single Bluetooth remote control

Press and hold the remote control until the indicator flashes twice blue (after deleting, if you need to add again, follow the adding method. After the addition is successful, the lock core prompts: Re-adding the user is a successful addition)