


Remote (2-Key, Zigbee) EN


User Manual



Overview

Linkoze Wireless Switch is a smart controller for other Linkoze smart home devices. It contains 2 keys and each of them is able to recognize three different gestures, click, double click, and long press.

The wireless switch requires a Linkoze gateway to connect to the Zigbee network and the internet.




App Installation

Meshhub App is the mobile platform for controlling Linkoze devices. You can search "Meshhub" in the mobile application store to install the App.



Activate the Device

Slide down the rear cover to open the device case. Then put a CR2032 battery into the product.



Device Pairing

Press the reset button of the wireless switch for 10 seconds then release. The device is ready to be paired when the indicator light starts to flash together.



Open the application and click the "+" button in the upper right corner, click the swipe button, scan the QR code on the package to connect the device, or click "Device" and select Zigbee, and follow the




Click the "+" button



Scan QR code

Key Automation Setup

Long press the device button on the main page to go to the control page where you can create cloud automations and bind them to the switch keys.



Long press the device button



Device control panel

Specifications

- Dimensions: 51.2 x 51.2x 12.6 mm
- Weight: 20g
- Key Number: 2
- Wireless Protocol: Zigbee
- Working Voltage: DC 3V
- Battery Type: CR2032