






Catalogue

- Applicable size .....01
- Product components .....03
- 1.Passcode: Flow chart .....04
- 2.RFID card:Flow char
- 3.Other settings: Flow chart .....05
- Accessories list (TOOL BOX) .....06
- Small Handle
- Install battery
- Adjust the length of the cylinder.....07
- Installation pictures
- Uresetting diagram
- Unlock and lock .....08
- FAQ
- Bluetooth activation and login instructions .....09
- Select"Android/iOS"to download
- Log in to the app
- Bind the device .....10
- Specifications .....11
- Operating instruction









40.60.12.1113



Applicable size







Product Components




Accessories list (TOOL BOX)


If there is a lack of accessories, please contact customer service in time.




Install battery




1. Loosen the screws with allen key




2. Open the stainless steel cover




3. Open the battery cover



4.3 \* AAA battery (Please buy it by yourself)







5. Install battery




6. Fix the battery cover and tighten the screws

Adjusting the length of the lock cylinder




In accordance with the required lock cylinder length, you can adjust the internal and external length by loosening the screw with an inner hexagon spanner and pulling out the handle as needed; if necessary, you can increase the lock cylinder length by using an extended lock cylinder piece and tighten the screw after adjustment. Plugged the adjusting hole with a silicone plug, which can play a certain waterproof role.




Spare lock cylinder extension, which can increase the length of the lock cylinder if necessary.




Due to the security reason, the front handle cannot be taken off.




Installation pictures




1. Remove the fixing screw and original cylinder




2. Take out the screws and take out the rear handle




3. The lock cylinder is installed into the lock hole from the outside



4. Installation Fixing screws




5. Install rear handle




6. Fixed rear handle screw


Uresetting diagram




1. Opening the silicone cover



2. Find the Thimble in the attached accessories





3. Find the hole where the reset button is located



4. Insert the thimble into the hole and press the reset button


Unlock and lock

Unlock the door from outside



The knob can be rotated 360 degree freely after locked.

To protect the lock not be damaged by torsion forcefully.



Low battery prompt:

After waking up, the screen displays:

After 3 "beep beep beep" beeps The screen prompts: "Battery Low".

Battery Low

Please replace the battery promptly when the above message appears.

FAQ


- What should I do when I receive the lock?**  
When you received the lock, please modify the default password "123456" to your own admin password first, so please keep it in your mind.
- Where can I find the lock ID?**  
Please find the lock ID with 8 digits number on the middle of lock, or find it on packing box.
- When will the low battery alarm?**  
The battery is below 20%.
- What is the USB backup key for?**  
USB backup key is spare key, for emergency situations, like when the lock is broken or battery run out, then you can use power bank to charge the lock via USB cable, then use our app to unlock the lock.
- How can contact customer service?**  
Please contact this email: [Service@WelockGlobal.com](mailto:Service@WelockGlobal.com)

Bluetooth activation and login instructions

Scan the QR code on the lock




Select "Android/iOS" to download





Log in to the app

- Select your country/region
- Enter the phone number/email to get the verification code
- Click "Send"
- Enter the verification code after receiving the message
- Click "Login"



Bind the device



5

Specifications

| Brand                 | WELOCK                             |
|-----------------------|------------------------------------|
| Applicable door types | Wooden doors, Interior doors       |
| Adjustable range      | 30-70 mm                           |
| Operating Temperature | -25°C - 60°C                       |
| Pressing Cycle Times  | 100,000 Times                      |
| Material of handle    | Zine Alloy                         |
| Way to unlock         | Passcode / IC card / Bluetooth     |
| Battery Type          | 3* AAA Battery (Separate purchase) |
| Power input           | 3.6V-4.5V                          |
| Battery Replacement   | Replaceable                        |
| Color                 | Silver/ Black                      |
| Battery Life          | 10-12 months                       |

FAQ

- How can I know the lock is out of power?**  
Each time you use, there is a screen above the fingerprint device shows the power. Low battery suitable, APP will prompt low battery tips, and send text messages to the phone.
- Does the lock knob still works after I replaced the lock?**  
It still works. It only replace the cylinder. It won't effect the other function of the original lock.
- Will it read slowly or fail to recognize the fingerprint after long time using?**  
It won't. The fingerprint sensor has a special protect film on it.
- Is it complicated to set?**  
It's easy. You just need to use the thimble to press the set key to register the fingerprint. The screen will show you the function to choose and just press your fingerprint on it.
- If we install all the houses' doors with We.Lock, can we use the phone APP to unlock all of it?**  
Yes, you can. One phone can in charge many different locks. Just remember to mark the name of each lock.
- Online Service:**  
Email : [service@welockglobal.com](mailto:service@welockglobal.com)