




WELOCK Smart Lock U81 Instruction





EN



Tips for Use:

1. After you received the lock, please set your admin password to the lock first.
(Please note: Before setting admin password, the smart lock is in default factory settings, so any password / fingerprint / card can unlock the lock.)
2. Before receiving the correct unlock command, the handle of smart lock is able to rotate 360° which is normal.

DE



Tipps für die Verwendung:

1. Nachdem Sie das elektronisches türschloss erhalten haben, richten Sie bitte zuerst Ihren Admin-Passwort auf dem elektronisches türschloss ein.
(Bitte beachten: Vor der Einstellung des Admin-Passwort ist das elektronisches türschloss auf die Werkseinstellungen zurückgesetzt, so dass jeder Fingerabdruck/Passwort/RFID Karte das elektronisches türschloss entsperren kann)
2. Bevor der richtige Entriegelungsbefehl empfangen wird, kann der Griff des elektronisches türschloss um 360° gedreht werden, was normal ist.

IT



Consigli per l'uso:

1. Dopo aver ricevuto lo serratura smart, impostare prima l'password dell'amministratore sullo serratura smart.
(Nota bene:Prima di impostare l'password dell'amministratore, lo serratura smart è nelle impostazioni di fabbrica predefinite,in modo che qualsiasi password/ impronta digitale/ RFID carta possa sbloccare la serratura smart.)
2. Prima di ricevere il comando di sblocco corretto, la maniglia dello serratura smart è in grado di ruotare di 360°, il che è normale.

FR



Conseils d'utilisation :

1. Après avoir reçu la serrure connectée, veuillez d'abord configurer votre mot de passe d'administrateur sur la serrure connectée.
(À noter: Avant de configurer l'mot de passe de l'administrateur, la serrure connectée est configurée par défaut en usine, de sorte que n'importe quelle mot de passe/ e mpreinte digitale/ RFID carte peut déverrouiller la serrure connectée.)
2. Avant de recevoir la commande de déverrouillage correcte, la poignée de la serrure connectée peut tourner de 360°, ce qui est normal.

ES




Consejos de uso:


1. Después de recibir la cerradura inteligente, por favor, establezca su contraseña de administrador a la cerradura inteligente en primer lugar.
(Atención: Antes de configurar la contraseña de administrador, la cerradura inteligente se encuentra en la configuración predeterminada de fábrica, por lo que cualquier contraseña/ huella dactilar / RFID tarjeta puede desbloquear la cerradura inteligente.)
2. Antes de recibir la orden de desbloqueo correcta, la manilla de la cerradura inteligente puede girar 360°, lo cual es normal.


Catalogue

• Suitable Installation conditions	01
• Product components	03
• Accessories list (TOOL BOX)	04
• Install battery	
• Installation pictures	05
• Setting operation	06
• Unlock and lock	08
• Bluetooth activation and login instructions	09
• Select "Android/iOS" to download	
• Log in to the app	
• Bind the device	10
• Specifications	11
• FAQ	








Applicable size





Product Components



Accessories list(TOOL BOX)

If there is a lack of accessories, please contact customer service in time.



RFID card * 3



Key*2



Silicone sleeve *1



Lock cylinder extension * 1



Cross screw *1



Allen key * 1



Fix screw for battery cover*1



Rear handle screw*1



Manual

Front cover plate




Rear cover plate




Door thickness in 50-60mm, add the cover plate for adjustment. Also can be used as a decorative cover.


Install battery




1. Loosen the screws with allen key




2. Pull out the battery compartment



3. Open the battery cover




4. 4*AAA battery (Not included in package)




5. Install battery

Note: 1.Keep mind the battery polars
2. Do not mix old and new batteries




6. Fix the battery cover and tighten the screws


Installation pictures




1. Take out the screws and take out the rear handle




2. Insert the allen key, take out the front handle




3. Rotating square axle to align the cam with the lock cylinder, install the lock cylinder into the door.




4. Align the screw holes of the insert with the screw holes of the lock body, install fixing screw.




5. Rotating square axle to raise the cam, insert allen key into the bottom of lock cylinder. Insert the front handle and adjust it to the fit position.



6. Pull out the screwdriver.






7. Install the rear handle to the fit position. Rear handle screw holes must be aligned with the square bar locating holes.



8. Fix rear handle screw

Setting operation





Scan the QR code on the lock

Download instructions & Watch Videos

A smart way to open your door.WELOCK
www.WELOCK.com


Unlock and lock

Unlock the door from outside

PRESS
Any button
to wake up lock





Passcode +




Enter the wrong passcode 5 times in a row, the smart lock will be locked for 90 seconds and cannot be operated.



Press any key to wake up



Press any key to wake up



Mechanical key unlock



The front and rear knob can be rotated 360° freely after locked.
To protect the lock not be damaged by torsion forcefully.



Low battery prompt:

After waking up,
the screen displays:




Battery
Low

Battery Low

Before unlocking the door, the
fingerprint light flashes red 5 times
with "beep beep beep"
The screen prompts: "Battery Low"


Please replace the battery promptly
when the above message appears.

Bluetooth activation and login instructions

Scan the QR code on the lock




Select "Android/iOS" to download




Log in to the app

- ① Select your country/region
- ② Enter the phone number/email to get the verification code
- ③ Click "Send"
- ④ Enter the verification code after receiving the message
- ⑤ Click "Login"



Bind the device



Specifications

Brand	WELOCK
Applicable door types	Wooden doors, interior doors, entrance doors etc
Operating Temperature	-25°C-60°C
Pressing Cycle Times	100,000 Times
Material of handle	Stainless steel+PC Plastic
Way to unlock	Fingerprint/Passcode/Rfid card /APP/ Mechanical key
Battery Type	4* AAABattery(Separate purchase)
Low voltage alarm	4.5V
Battery Replacement	Replaceable
Color	Silver
Battery Life	10-12 months

FAQ

- **How can i know the lock is out of power?**
Each time you use, the screen shows the power.
APP will prompt low battery tips.
- **Does the lock knob still works after I replaced the lock?**
It still works.It only replace the cylinder . It won't effect the other function of the original lock.
- **Will it read slowly or fail to recognize the fingerprint after long time using?**
It won't. The fingerprint sensor has a special protectfilm on it.
- **Is it complicated to set?**
Follow the instructions or search the welock set up video through YouTube to set up the smart lock, if you have any questions please contact our customer service.
- **If we install all the houses' doors with WELOCK, can we use the phone APP to unlock all of it?**
Yes, you can.One phone can in charge many different locks.Just remember to mark the name of each lock.
- **Online Service:**
Email :service@welockglobal.com