

Smart Pet Fountain

Quick Guide User Manual

V1.0

Content

Please read this manual carefully before operation to ensure safe usage of the pet fountain. This instruction manual is suitable for the multi-function version and the basic version of pet fountain , the basic version will not be introduced repeatedly.

Pet Fountain
(subject to the actual product)

List of accessories
(subject to the actual product)

Adapter X1

Anti-break bite power cord X1

User manual

product introduction

Structure introduction

Operation guide

1.First usage

①. Please take out pet fountain and accessories

②. Please clean inner wall and top cover of water storage bucket and filter core

③. please insert filter core into the filter core slot at the bottom of the top cover after immersing the filter element in clean water for 2 minutes,

④. Please add water to the transparent water bucket above the MIN line and below the MAX line.

⑤. Please take the adapter and plug it into the USB interface of the button of pet fountain

⑥. Please press the button on the front body of pet fountain to turn on and off the water feeding function, and please press the button for long time(around 6 to 7 seconds) to restore factory default settings, it will comes to network configuration status(network indicator flashes)

2. Binding Smart Life APP

2.1:APP download and installation

Please scan the QR code below or QR code on the packing box to download Smart Life app and complete the installation

2.2: App Registration

①.APP Please open "Smart Life" APP

②. Please click "create new account"

③. Please select the time zone to input the account to get verification code

④. Please input the received verification code for verification

⑤. Please set up login password and login successfully.

3.3: Pet Fountain Configuration

①. Please log in APP to add device

②. Click "Pet Fountain"

③. Confirm indicator rapidly blink

④. Enter Wi-Fi Password

⑤. Connecting....

⑥. Device added successfully

三、Pet Fountain Interface Introduction

Pet Fountain Interface Introduction

①. Setting : other function

②. Switch

③. Switch

④. Timing

⑤. Disinfect

Setting

①. Device Name

②. Device Information

③. ap-to -Run and Automation

④. Offline Notification

⑤. Share Device

⑥. FAQ & Feedback

⑦. Add to Home Screen

⑧. Check Device Network

(1) .Remove

(2) .Reset

Adding Water Instruction

APP alarm push for lowest water level

Clean Instruction

Recommended to clean at least once per week and change water to prevent poor water quality or poor outlet water caused by filtration blockage.

Attention

1. Be sure to clean the power after disconnecting the power supply.

2. Do not immerse the pet fountain body and power adapter in water.

3. For the first time, please clean the inside of the transparent water tank, top cover and the filter slot .

4. The filter may be attached with a small amount of powder. This is a normal phenomenon. Rinse .

5. The filter is recommended to be replaced once a month.

Warning

1. Pet fountain and all accessories are not edible.

2. Please use pet fountain in a dry indoor environment.

3. Do not place pet fountain in a high place.

4. Keep the pet fountain horizontal when using it. Do not tilt or tip it.

5. Do not add hot water or boiling water in the water tank to avoid hot deformation.

6. Please make sure that the power cable is blocked and stored to avoid leakage damage caused by pet bites. The power supply is in safe working voltage, does not endanger the safety of pets and owners.

7. Do not disassemble or repair the pet fountain, otherwise affecting the after-sales.

8. Please do not use any accessories that are not provided by the original manufacturer. We are only responsible for the performance and safety of the officially designated accessories.

FAQ

Q. How often does pet fountain change the water and how often we need to clean it?
A. According to the water quality and pet drinking habits. It is recommended to replace or add water every 2-3 days; it is recommended to clean at least once a week (including water tank, top cover, filter slot, filter), and completely change the water to prevent fouling from clogging the filter slot, resulting in abnormal water quality
Do not use hot water or boiling water when cleaning.

Q. What kinds of water should be used in the pet fountain?
A. It is recommended to use pure water or mineral water.

Q. How often does filter need to be replaced?
A. The filter is recommended to be replaced once a month to maintain a good filter effect.

Q. Does the pet fountain consume lots of power? is there any noise?
A. It has low working power (MAX4.5W) and consumes about 1 kWh in 10 days.
The product adopts silent pump and noise reduction design, working without noise. (There is natural water sounds to attract pets to drink plenty of water.)

Q. Is there any safety hazard when the power cable of the pet fountain is bitten by a pet?
A. The power supply adopts 5V low voltage and 0.6A low current to ensure the safety of pets. Friendly reminder: use broken power cable will have a hazards of pets eating, please replace it in time.

Q. What are the most suitable cats and dogs for pet fountain?
A. Suitable for adult cats and small and medium dogs.

Q:What is the reason that the pet fountain does not work after it is powered on?

Repair form

Commodity maintenance record

Repair time

Repair failure

cause of issue

Troubleshooting

Return certificate

Validation date

Original device ID

New device ID

Signature of maintenance personnel

Maintenance department stamp