














Size : 90*50 MM

Wi-Fi IR+RF Remote Control USER MANUAL  Model: S12 -1-	Thanks for choosing our product ! Say goodbye to remote controls of the IR home appliances such as TV, Air-con, TV box, light, Fan, Audio, etc. You can remotely control these devices with the tap of your finger on the mobile App, also you can control RF-enabled devices like curtain, roller shutter, garage door, RF switch, etc. Please read the user manual carefully before use and keep it for future reference. Product Presentation  -2-	Product Specification Size: Φ75*20mm Input: DC 5V/1A LED Indicator: Blue Infrared Frequency: 38KHz Infrared Range: ≤ 12 Meters Wi-Fi Protocol: 2.4GHz Wi-Fi Standard: IEEE 802.11 b/g/n Radio Frequency: 433/315MHz -3-	Checklist before using the device: a. Your smartphone has connected to 2.4GHz Wi-Fi network. b. Input the correct Wi-Fi password. c. Your smartphone must be Android 6.0 + or iOS 11 +. d. If the numbers of devices connected to the Wi-Fi router reach the limit, you can try to disable a device to vacate the channel or try with another router. -4-	How to set up: 1. Use your smartphone to scan below QR code, or search "Smart Life" app in Google Play Store or APP Store to download and install.  2. Create an account with your mobile number and authentication code.  -5-	3. Connect your mobile to your Wi-Fi router , supply power to the remote control with supplied charging cable, click "+" in the upper right corner of homepage or click "Add Device" .  4. 1) Bluetooth Mode: The app will advise you to turn on the bluetooth on your mobile, make sure the indicator is flashing, if not, hold the reset button till it is flashing, enter wifi info, it will connect automatically. -6-
  -7-	2) WiFi Mode: Select " Universal Remote Control (Wi-Fi + BLE)" from " Others ". Select " Blink Slowly ", make sure the indicator is blinking slowly, if not, hold the reset button till the indicator is blinking slowly. Connect your mobile to the device's hotspot:"SmartLife-XXXX", then click to return to App interface, it will connect automatically.  -8-	  -9-	5. Tap " IR+RF Remote Control", click "Infrared Remote Box", select the IR device and its brand you need control, please select "Manual Mode" to match at least 3 buttons to check if the device reacts properly, if yes, match complete, you can control it now.  -10-	6. After adding the device, if you want to edit the name , For Android, long press the box, it will pop up "Rename", click it to edit. For iOS, slide the box towards left, choose "Rename".  -11-	7. If you can not find the brand of the device in the brand list, you click "DIY" to learn the buttons of other brands' remote control, so you can also control the device.  Step 1 Step 2 -12-
 Step 3  Step 4  Step 5  Step 6 -13-	8. You can click "+" to continue to copy other buttons or click "Finish". Notes: 1. It only support 38KHz frequency, if the IR remote unable to receive commands from the IR device, it is likely that the frequency of IR device does not match, unable to study commands. 2. DIY does not support voice control. -14-	9. You can also control the RF-enabled devices by DIY learning buttons of RF device's remote control. Once button is learned successfully, press the button to check whether it works.  -15-	  -16-	Functions 1. Customize Scenario Create smart scenario for IR devices, click "Scene" page, then click "+" at the upper right corner to set conditions and tasks.  -17-	2. Remote control You can control IR/RF devices remotely wherever you are at anytime on the mobile app. 3. Set Schedule Select "Tap to Run" or " Automation" in "Scene" page, tap "+" to select "Schedule" to set power on/off.  -18-
4. Share devices You can share added devices with your family members, so they can also control the devices.  5. Third-party Voice Control Works with amazon alexa and google assistant. -19-	FAQ 1.What voltage of adapter should i use? Please ONLY use 5V power adapter to supply power, and make sure the current of adapter is full 1A. Otherwise, the IR RF Remote will not work properly. 2. What should we do when we can not use IR remote to control device? IR can not penetrate walls, so make sure there is no obstacle between IR remote and the IR devices. 3. Can i control devices through 2G/3G /4G network? Both IR remote and mobile device are required to share the same wifi network when adding the IR remote. After configuration done, you can control devices through 2G/3G/4G network. Currently it does not support 5G network. -20-	4. What should i do when device configuration process fail? You can: 1)Check whether IR remote is powered on or not. 2)Check whether your mobile phone is connected to 2.4GHz wifi network. 3)Check your network connectivity, make sure the Wi-Fi router is working properly. 4)Make sure the wifi password is correct. 5. What should i do if the device is often offline? 1)Check whether the router is powered off or disconnected from the network. 2)Check whether the router has been replaced, or Wi-Fi name or password has been changed. -21-	3)Please confirm whether the device has just updated the firmware. The device will be disconnected from the network when the firmware is updated, and will automatically connect to the network after update completed. 4)The Wi-Fi signal of the device is too poor. 5)The location of the device is too far away from the router 6)If the device goes offline after a period of use, but after restarting the router or re-networking the device, the device returns to normal. Indicating the router is overloaded due to long-term high-load use, you need to replace it with a more powerful one, or reduce the number of devices connected to the router. 7)You can also use phone hotspot to check whether it is the problem of network. -22-	6. What should i do when DIY learning the buttons for IR device? It only supports 38KHz IR frequency, if IR remote unable to receive commands from the IR device, it is likely that the frequency of IR device does not match, unable to study commands. So please check IR frequency of the device. 7. What should we do when we learn the buttons of RF devices? 1)When App pops up the window, long press the button till it shows learning succeeded, if fail after trying 3 times , please try to short press the buttons. 2)RF remote only supports fixed radio frequency 315MHz and 433.92 MHz. 3)For devices with higher security needs, some remotes of them use rolling code and encrypted code. so you can not copy the buttons. The fixed codes include 1527 series, PT 2262 /2264 /2267, the rolling code includes HCS 301/300. -23-	-24-