








尺寸：53x80mm（折页）
材质：80g 双铜
印刷：彩页
MC400S 门磁

Smart WiFi Door Window Alarm  * Please read this manual carefully before use and keep it for future reference.	Specifications: Input voltage: DC3V LR03 Quiescent Current: ≤55uA Alarm Current: ≤180mA Low power undervoltage: ≤2.4V WiFi standard: 802.11b/g/n Magnetic control distance: ≤ 15MM Alarm decibel: ≤ 90dB 1meter Working temperature: -10℃~+50℃ Working humidity: Max 95%RH 2	How to use : 1. Push the mounting bracket upward and take out the bracket, then insert the battery.  2. Put the battery into the battery bin and place it according to the graphics in the battery bin. After two batteries are loaded, the indicator lights are always on and then off. 3	 3. Download SmartLife APP in app store or google play store, or scan the following QR code.  Android/iOS 4. Login App by mobile number or email. 5. There are three methods for configuration. 4	5.1 Configuration by EZ mode. Long press reset key of device for more 5 seconds until the indicator light flashes quickly, then click App "My Home" interface + "or" Add Devices → sensors → sensors (BLE+WiFi) → Confirm the indicator is blinking → Blink quickly → Select WiFi and Input password to start configuration (2.4G WiFi only, it can not work with 5G)  5	5.2 Configuration by Bluetooth. Turn on Bluetooth on mobile phone and refer to below steps.  6
 7	5.3 Configuration by AP mode. Long press reset key of device for more 5 seconds until the indicator light blinks quickly, then press again until light into blinks slowly → click App "My Home" interface "+" or "Add Devices" → "sensors" → "sensors(BLE+WiFi)" → "Confirm the indicator is blinking " → "Blink slowly" → go to connect → select "SmartLife-XXXX" by your WiFi list and then return APP → OK 8	 9	 10	6. After configuration success, put magnet and detector separate or together to test if the device state in App is changing and receive notifications.  11	7. In case of emergency, you can press and hold the button on the front of the product for more than 3 seconds, and the product sends an alarm sound APP push (short press the front button to stop the alarm) 8. Turn on/off siren settings: Long press the button on the front of the product for 3 seconds to enter the SOS, and do not release the button for 6 seconds to enter the on/off alarm. (If it is turned on by default, press 6 seconds to turn off the alarm, and then press again for 6 seconds to turn on) 10. OTA updates. ※ Press reset key 5 times continuously until indicator light keep on, click "find new firmware" to update by App. ※ Device reports battery level to Cloud in every 8 hours, will offline if doesn't report in 3 times continuously. 12