

80.00 mm	
120.00 mm	
CONTENTS	
INTRODUCTION	INSTALLATION
1	3
STANDALONE MODE	CONTROLLER MODE
5	12
WIEGAND READER MODE	ADVANCED APPLICATION
14	15

INTRODUCTION	
The device is a single door multifunction standalone access controller or a Wiegand output reader. It uses Atmel MCU assuming stable performance. The operation is very user-friendly, and low-power circuit makes it long service life.	
The device can be used with Bluetooth Version or with WIFI Version.	
Features	
> Metal case, anti-vandal	
> Waterproof, conforms to IP66	
> PIN length: 4-6 digits	
> EM card, EM+Mifare cards optional	
> EM card: Wiegand 26-44 bits input & output	
> Mifare card: Wiegand 26-44bits, 56bits, 58bits input & output	
> Can be used as Wiegand reader with LED & buzzer output	
> Card block enrollment	
> Tri-color LED status display	
> Integrated alarm & buzzer output	
> Pulse mode, Toggle mode	
> User data can be transferred	
> 2 devices can be interlocked for 2 doors	
> Built-in light dependent resistor (LDR) for anti tamper	
> Backlit keypad, can set automatic OFF after 20 seconds	
Specifications	
User Capacity	10000
Common User	9988
Panic User	2
Visitor User	10
Operating Voltage	12-18V DC
Working Current	≤150mA
Idle Current	≤60mA
Proximity Card Reader	EM / EM+ Mifare
Radio Technology	125KHz / 125KHz + 13.56MHz
Read Range	2-6 cm
PIN Length	4-6 digits
Wiring Connections	Relay Output, Exit Button, Alarm, Door Contact, Wiegand Input, Wiegand Output

Relay	
Adjustable Relay Output Time	One (NO, NC, Common)
Lock Output Load	0-99 Seconds (5 seconds default)
	2 Amp Maximum
Wiegand Interface	
EM card: Wiegand 26-44 bits input & output.	
Mifare card: Wiegand 26-44bits, 56bits, 58bits input & output.	
(Factory default: Wiegand 26bits for EM card, Wiegand 56bits for Mifare card)	
4 bits, 8 bits(ASCII), 10 digits Virtual Number	
(Factory Default: 4 bits)	
Environment	
Operating Temperature	Meets IP66
Operating Humidity	-40°C ~ 60°C (-40°F ~ 140°F)
	0%RH~95%RH
Physical	
Colour	Zinc-Alloy (A/B/D/E)
Dimensions	ABS(C)
	Silver & Black (A/B/D/E)
	Black(C)
	L148 x W43.5 x D22 (mm) -- A/C
	L165 x W44 x D22 (mm) -- B
	L133 x W71 x D22 (mm) -- D
	L147 x W71 x D22 (mm) -- E
Unit Weight	330g -- A 415g -- B 190g -- C
	500g -- D 500g -- E 280g -- C
Shipping Weight	405g -- A 500g -- B 280g -- C
	600g -- D 600g -- E
Carton Inventory	
	A B C D E
	Diode 1N4004 (For relay circuit protection)
	Wall Anchors
	Self Tapping Screws: Φ4*25mm
	Screw Driver
	Master Card
	Master Card

INSTALLATION		
> Remove the back cover from the unit		
> Drill 2 holes(A,C) on the wall for the screws and one hole for the cable		
> Knock the supplied rubber bungs to the screw holes(A,C)		
> Fix the back cover firmly on the wall with 4 flat head screws		
> Thread the cable through the cable hole(B)		
> Attach the unit to the back cover		
Wiring		
Wire Color	Function	Notes
Basic Standalone Wiring		
Red	DC+	12-18V DC Power Input
Black	GND	Negative Pole of DC Power Input
Blue & Black	Relay NO	Normally Open Relay Output (install diode provided)
White & Black	Relay Common	Common Connection for Relay Output
Green & Black	Relay NC	Normally Closed Relay Output (install diode provided)
Yellow	OPEN	Request to Exit(REX) Input
Pass-Through Wiring (Wiegand Reader or Controller)		
Green	Data 0	Wiegand Output (Pass-through) Data 0
White	Data 1	Wiegand Output (Pass-through) Data 1
Advanced Input and Output Features		
Grey	Alarm Output	Negative contact for Alarm
Brown	Contact Input	Door/Gate Contact Input (Normally Closed)
WIFI Version with Doorbell		
Brown & Black	Doorbell A	Contact for Doorbell
Yellow & Black	Doorbell B	Contact for Doorbell

Sound and Light Indication		
Operation Status	LED	Buzzer
Stand by	Red light bright	—
Enter into programming mode	Red light shines	One beep
In the programming mode	Orange light bright	One beep
Operation error	—	Three beeps
Exit from the Programming mode	Red light bright	One beep
Open lock	Green light bright	One beep
Alarm	Red light Shines quickly	Beeps
Basic Configure		
Enter and Exit Program Mode		
Programming Step	Keystroke Combination	
Enter Program Mode	★ (Master Code) #	
Exit Program Mode	★	
Set Master Code		
Programming Step	Keystroke Combination	
1. Enter Program Mode	★ (Master Code) #	
2. Update Master Code	0 (New Master Code) # (Repeat New Master Code) #	
3. Exit Program Mode	★	
Set the Working Mode		
Notes: The device has 3 working modes: Standalone Mode, Controller Mode, Wiegand Reader Mode, choose the mode you use. (Factory default is Standalone Mode / Controller Mode)		
Programming Step	Keystroke Combination	
1. Enter Program Mode	★ (Master Code) #	
2. Standalone/Controller Mode OR	7 7 # (Factory default)	
2. Wiegand Reader Mode	7 8 #	
3. Exit	★	

STANDALONE MODE		
The device can work as Standalone Access Control for single door.		
(Factory default mode) — 7 7 #		
Connection Diagram		
Common Power Supply		
Attention: Install a 1N4004 or equivalent diode is needed when use a common power supply, or the keypad might be damaged. (1N4004 is included in the packing)		

Access Control Power Supply		
Programming		
Programming will be very depending on access configuration. Follow the instructions according to your access configuration.		
Notes:		
> User ID number: Assign a user ID to the access card / PIN in order to track it.		
> User ID number:		
The Common Card/PIN User ID: 1-9988		
Panic User ID: 9989-9990		
Visitor User ID: 9991-10000		
IMPORTANT: User IDs do not have to be proceeded with any leading zeros. Recording of User ID is critical. Modifications to the user require the User ID be available.		
> Proximity Card:		
Proximity Card: EM card/ EM+ Mifare cards		
> PIN: Can be any 4-6 digits.		

Add Common Users		
(PIN/ Card user ID: 1-9988; PIN length: 4-6 digits)		
Programming Step		
1. Enter Program Mode		
★ (Master Code) #		
Add Card User		
2. Using Auto ID		
(Allows the device to assign Card to next available User ID number)		
OR		
2. Select Specific ID		
(Allows Master to define a specific User ID to associate the card to)		
OR		
2. Add Card: Block Enrollment		
(Allows Master to add up to 200 cards to the Reader in a single step)		
Takes 2 minutes to program.		
Add PIN User		
2. Select Specific ID		
(Allows manager to define a specific User ID to associate the PIN to)		
3. Exit		
★		
Tips for PIN Security (Only valid for 6 digits PIN):		
For higher security we allow you to hide your correct PIN with other numbers up to a max of 10 digits.		
Example PIN: 123434		
You could use **123434** or **123434**		
(**" can be any numbers from 0-9)		
Add Panic Users (Valid for Card/ PIN Users)		
(User ID number is 9989,9990 PIN length: 4-6 digits)		
Programming Step		
1. Enter Program Mode		
★ (Master Code) #		
2. Add Card		
1 (User ID) # (Read Card / Input 8/10/17 Digits Card number) #		
3. Exit		
★		

OR		
2. Add PIN		
1 (User ID) # (PIN) #		
3. Exit		
★		
Add Visitor Users (Valid for Card/ PIN Users)		
(User ID number is 9991-10000 PIN length: 4-6 digits)		
There are 10 groups Visitor PIN/card available, the users can be specified up to 10 times of usage, after a certain number of times, i.e. 5 times, the PIN/card become invalid automatically.		
Programming Step		
1. Enter Program Mode		
★ (Master Code) #		
2. Add Card		
OR		
2. Add PIN		
1 (User ID) # (0-9) # (Read Card) / (Input 8/10/17 Digits Card Number) #		
OR		
1 (User ID) # (0-9) # (PIN) #		
(0-9 means times of usage, 0=10 times)		
3. Exit		
★		
Change PIN Users(PIN length: 4-6 digits)		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Add Card		
OR		
2. Add PIN		
1 (User ID) # (0-9) # (Read Card) / (Input 8/10/17 Digits Card Number) #		
OR		
1 (User ID) # (0-9) # (PIN) #		
(0-9 means times of usage, 0=10 times)		
3. Exit		
★		
Delete Users		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Delete User- By Card		
OR		
2. Delete User - By ID number		
OR		
2. Delete User - By Card number		
OR		
2. Delete ALL Users		
2 (Input 8/10/17 Digits Card Number) #		
3. Exit		
★		

Set Relay Configuration		
The relay configuration sets the behaviour of the output relay on activation.		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Pulse Mode		
OR		
2. Toggle Mode		
3. Exit		
★		
Set Access Mode		
For Multi user access mode, the interval time of reading can not exceed 5 seconds, or else, the device will exit to standby automatically.		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Card Access		
OR		
2. PIN Access		
OR		
2. Card or PIN		
OR		
2. Multi User Access		
4 3 # (factory default)		
4 3 (2-9) #		
(Only after 2-9 valid users, the door can be opened)		
3. Exit		
★		
Set Strike-out Alarm		
The strike-out alarm will engage after 10 failed entry attempts (Factory is OFF). It can be set to deny access for 10 minutes after exiting or disengage only after entering a valid card/ PIN or Master code/ card.		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Strike-Out OFF		
OR		
2. Strike-Out ON		
6 0 # (factory default)		
3. Exit		
★		

Simplified Instruction	
Function Description	Operation
Enter the Programming Mode	★ - Master Code - #
	then you can do the programming (123456 is the factory default master code)
Change the Master Code	0 - New Code - # - Repeat the New Code - #
	(code: 6 digits)
Add Card User	1 - Read Card - #
	(can add cards continuously)
Add PIN User	1 (User ID) - PIN - #
	(The PIN is any 4-6 digits)
Delete User	2 - Read Card - #
	2 - User ID - #
Exit from the Programming Mode	★
How to release the door	Read Card
Card User	Input PIN #

2. Strike-Out ON		
OR		
2. Strike-Out ON (Alarm)		
Set Alarm Time		
5 (0-3) # (factory default is 1 minute)		
Enter Master Code # or Master Card or valid user Card / PIN to silence		
3. Exit		
★		
Set Door Open Detection		
Door Open Too Long (DOTL) Detection		
When use with an optional magnetic contact or built-in magnetic contact of the lock, if the door is opened normally, but not closed after 1 minute, the inside buzzer will beep automatically to remind people to close the door. The beep can be stopped by closing the door, master users or valid users, or else, it will continue to beep the same time with the alarm time set.		
Door Forced Open Detection		
When use with an optional magnetic contact or built-in magnetic contact of the lock, if the door is opened by force, the inside buzzer and external alarm (if there is) will both operate, they can be stopped by master users or valid users, or else, it will continue to beep the same time with the alarm time set.		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Disable Door Open Detection		
OR		
2. Enable Door Open Detection		
Set Alarm Time		
5 (0-3) # (factory default is 1 minute)		
3. Exit		
★		
The function of Set Alarm Time also apply for anti-tamper alarm		
Set Audible and Visual Response		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Disable Sound		
OR		
2. Enable Sound		
7 0 #		
7 1 # (factory default)		

2. LED Always OFF		
LED Always ON		
OR		
2. Keypad Backlit Always OFF		
Keypad Backlit Always ON		
Keypad Backlit Automatic OFF		
3. Exit		
★		
Master Card Usage		
Using Master Card to add and delete users		
Add Card/ PIN Users		
1. Read Master Card		
2. Read Card or Input User ID-PIN #		
Repeat step 2 for additional users		
3. Read Master Card again		
Delete Card/ PIN Users		
1. Read Master Card Twice within 5s		
2. Read Card or Input User ID-PIN #		
Repeat step 2 for additional users		
3. Read Master Card again		
Users Operation & Reset to Factory Default		
> Open the door: Read valid user card or input valid user PIN #		
> Remove Alarm: Enter Master Code # or Master Card or valid user Card / PIN		
> To reset to factory default & Add Master Card: Power off, press the Exit Button, hold it and power on, there will be two beeps, then release the exit button, the LED light turns into yellow, then read any 125KHz EM card / 13.56MHz Mifare card, the LED will turn into red, means reset to factory default successfully. Of the card reading, it is the Master Card.		
Remarks:		
① If no Master Card added, must press the Exit Button for at least 5 seconds before release, (this will make the previous registered Master Card invalid)		
② Reset to factory default, the user's information is still retained.		

CONTROLLER MODE		
The device can work as Controller, connected with the external Wiegand reader.		
(Factory default mode) — 7 7 #		
Connection Diagram		
Attention: Install a 1N4004 or equivalent diode is needed when use a common power supply, or the reader might be damaged. (1N4004 is included in the packing)		

Set Wiegand Input Formats		
Please set the Wiegand input formats according to the Wiegand output format of the external Reader.		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Wiegand Input Bits		
For EM Card: 8 (26-44) #		
(factory default is 26bits)		
For Mifare Card: 8 0 (26-44, 56, 58) #		
(factory default is 34bits)		
3. Disable Parity Bit		
8 0 #		
4. Exit		
★		
Note: For connecting Wiegand readers with 32, 40, 56 bits output, need disable parity bits.		
Programming		
> Basic Programming is the same as Standalone Mode		
> There are some exceptions for your attention:		
The device Connected with External Card Reader		
- If EM/Mifare card reader: users can be added/deleted on either the device or external reader.		
- If HID card reader: users can only be added/deleted on external reader.		
The device Connected with Fingerprint Reader		
For example:		
Connect SF1 as the fingerprint reader to the device.		
Step 1: Add the Fingerprint (A) on SF1 (Please refer to SF1 manual)		
Step 2: Add the same Fingerprint(A) on the device:		
1. Enter Program Mode: ★ (Master Code) #		
2. 1 (Press Fingerprint A once on SF1) # (ID auto allocated)		
OR		
2. 1 (User ID) # (Press Fingerprint A on SF1) # (Select specific ID)		
3. Exit: ★		

The device Connected with Keypad Reader		
The keypad reader can be 4 Bits, 8 Bits (ASCII), or 10 Bits output format. Choose the below operation according to the PIN output format of your reader.		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. PIN Input bits		
8 (4 or 8 or 10) # (factory default is 4 bits)		
3. Exit		
★		
Remarks: 4 means 4 bits, 8 means 8 bits, 10 means 10 digits virtual number.		
> Add PIN Users:		
To add PIN users, after enter into programming mode on the device, PIN(s) can be input/ added on either the device or the external Keypad Reader.		
> Delete PIN Users: the same way as add users.		
WIEGAND READER MODE		
The device can work as Standard Wiegand Reader, connected to the third party Controller — 7 8 #		
Connection Diagram		

Notes:		
> When set into Wiegand Reader mode, nearly all settings in Controller Mode will become invalid, and Brown & yellow wires will be redefined as below:		
- Brown wire: Green LED light control		
- Yellow wire: Buzzer control		
> If you need to connect Brown/Yellow wires:		
When the input voltage for LED is low, the LED will turn into Green; and when the input voltage for Buzzer is low, it will sound.		
Set Wiegand Output Formats		
Please set the Wiegand output formats of Reader according to the Wiegand input formats of the Controller.		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Wiegand output bits		
For EM Card: 8 (26-44) #		
(factory default is 26bits)		
For Mifare Card: 8 0 (26-44, 56, 58) #		
(factory default is 34bits)		
8 (4 or 8 or 10) # (factory default is 4 bits)		
3. Disable Parity Bit		
8 0 #		
4. Exit		
★		
PIN output bits		
1. Enter Program Mode		
★ (Master Code) #		
2. Wiegand output bits		
For EM Card: 8 (26-44) #		
(factory default is 26bits)		
For Mifare Card: 8 0 (26-44, 56, 58) #		
(factory default is 34bits)		
8 (4 or 8 or 10) # (factory default is 4 bits)		
3. Disable Parity Bit		
8 0 #		
4. Exit		
★		
Note: For connecting Wiegand controller with 32, 40, 56 bits input, need disable parity bits.		
ADVANCED APPLICATION		
Collection Card Mode		
After this mode is turned on, all cards can open the lock. At the same time, the card is added to the device.		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Collection Card Mode OFF		
OR		
2. Collection Card Mode ON		
9 2 # (factory default)		
9 3 #		
3. Exit		
★		

User Information Transfer (Valid for Card / PIN Users)		
The device supports the User Information Transfer function, and the enrolled user (cards, PINs) can be transferred from one (let's name it Master Unit) to another (let's name it Accept Unit).		
Connection Diagram:		
Remarks:		
> The Master units and Accept units must be same series devices.		
> The Master Code of the Master Unit and the Accept Unit must be set to the same.		
> Program the transfer operation on Master Unit only.		
> If the Accept Unit is already with the users enrolled, it will be covered after transferring.		
> For full users enrolled, the transfer takes about 30 seconds.		
Set Transferring on Master Unit:		
Programming Step		
Keystroke Combination		
1. Enter the programming mode		
★ (Master Code) #		
2. Set transferring		
9 8 #		
3. Exit		
★		
Within 30 seconds, Green LED shines, after one beep, the LED will turn into red, which means the users' information has been transferred successfully.		
Interlock		
The device supports the Interlock Function. It is of two Devices for two doors, and mainly used for banks, prisons, and other places where a higher level security is required.		

Connection Diagram:		
The Device		
The Device		
Remarks: The Door Contact must be installed and connected as the diagram. Let's name the two Devices as "A" and "B" for two doors "1" and "2"		
Step 1:		
Enroll the users on Device A, then transfer the users' information to Device B by "User Information Transfer" function.		
Step 2:		
Set both of the two Devices (A and B) to Interlock function		
Programming Step		
Keystroke Combination		
1. Enter Program Mode		
★ (Master Code) #		
2. Disable Interlock		
OR		
2. Enable Interlock		
9 1 #		
3. Exit		
★		
If enable interlock, when and only door 2 is closed, the user can read the valid fingerprint/card or input PIN on Reader A, door 1 will open; then when and only door 1 closed, read valid fingerprint/card or input PIN on Reader B, door 2 will open.		

Access Control / Reader		
User Manual		