

WiFi smart multi-function door magnetic sensor



*Please read this manual carefully before use it, and keep it for future reference

Specification

Input Voltage: DC3V LR03

Static Current: $\leq 35\mu A$

Alarm Current: $\leq 135mA$

Low-voltage notification: $\leq 2.4V$

WiFi: 802.11b/g/n

Magnetic Control Distance: $\leq 20MM$

illumination range to detect: 0-10000Lux

Working Temperature: $-10^{\circ}C \sim +50^{\circ}C$

Working Humidity: Max 95%RH

1

How to use?


1. Download SmartLife App in Application store, or scan below QR code;



Android/iOS

2

2. Push the mounting bracket upward and take out the bracket, then insert the battery.



3. Put the battery into the battery bin and place it according to the graphics in the battery bin. After two batteries are loaded, the indicator lights are always on and then off.



3

4. Register with mobile phone number and log in to APP.


* Bluetooth Network Configuration

5. Turn on mobile phone Bluetooth; Use the PIN to press RESET till the LED indicator flashes quickly, App will search devices nearby automatically. The device will display once found.



4


6. Click 'Go to add' to enter the WiFi password according to prompt. And click 'Next' to start connection.



5


* WiFi Network Configuration

7. Register with mobile phone number and log in to App; Click "My Home" interface "+" or click "Add Devices" in the middle blank. Select 'Sensor' and choose 'Sensor (Wi-Fi)'.




6

8. Use the card PIN in the accessory package to hold RESET for more than 5 seconds, the indicator flashes quickly and waiting for network configuration. Enter the WiFi password according to the prompt, and click to 'Next' to start adding device.




7

9. When the indicator flashes quickly (EZ Mode as default), holds RESET for another 5 seconds with card PIN, the indicator flashes slowly, device enter manual network configuration (AP mode). App choose AP Mode, tick 'Confirm the indicator is blinking slowly' and click 'Next'. Click 'Go to Connect', mobile phone will switch to WLAN, find 'SmartLife-XXX' and click to connect. Return to APP current interface to continue adding device.



8

10. Network connection successfully, click 'DONE' to enter the interface of Door sensor.



9